Quick Start Guide – Steam Dryer

REGISTER YOUR PRODUCT

USA ONLY

Welcome to the Speed Queen® family. Thank you for your support of our truly commercial quality products. Please take a moment to register your product – it's quick and easy:

Simply go to www.speedqueen.com/register

Backed by Legendary 3, 5, 7 Year Parts & Labor Warranties.

Visit speedqueendoc.net to view Limited Warranty

Simplified warranty service | *Latest product info* | *Verification of ownership* | *Opt-in for latest offers & promotions*

Before Using

- ✓ Follow Safety and Installation Instructions
- ✓ Double check the following:
  - Dryer is leveled
  - Cold water supply is properly connected and there are no leaks
  - Ensure gas supply pipe is connected per local codes and ordinances (Gas models only) – see Installation Instructions for details
  - Exhaust ducts are clean and do not exceed maximum lengths found in Installation Instructions
  - Dryer is placed with enough clearance to not restrict rear exhaust
  - Dryer is plugged in
- ✓ Wipe out inside of dryer
- ✓ Start dryer and check that dryer is heating

Preparing Laundry/Tips

- ✓ Always check fabric care label for proper care instructions
- ✓ Separate lint shedding fabrics and lint receiving fabrics
- ✓ Separate no heat, low heat, and high heat items
- ✓ Separate lighter weight items prior to drying or remove the items when they are dry

Loading Laundry

- ✓ Load items loosely
- ✓ Determine load size based on bulk of load, rather than weight, leaving space for items to tumble freely
- ✓ Place large and small pieces together to make up loads which will tumble well
- ✓ Make sure load is not too small or it will not tumble properly, add a couple of large towels

Operating	
1. Prepare laundry	5. Set cycle
2. Clean lint filter by wiping lint out of screen area (if using lint filter guard, remove first)	6. Set temperature and dryness level
3. Load dryer 1/2 full with items and close door	7. Press start button to start
4. Turn on dryer by pressing power/cancel	8. Remove laundry from dryer once cycle has ended

Cycle	Use
Auto-Sensing (*Heavy Duty, Regular, Perm Press, Delicate)*	Cycle operation is determined by the type of cycle selected as well as the moisture sensing system. Set cycle based on load type. See Use and Care manual.
Manual *(Time Dry, Quick Dry)*	Time and temperature can be manually set. To adjust the time, use the up and down arrow keypads.
Pet Plus™ *(Pet Hair Remove, Pet Items)*	Use to dry, refresh, and remove hair from pet items. Use *Pet Hair Remover* to remove pet hair from dry items. Use *Pet Items* to dry and refresh bulky pet items.
Steam Sanitize	A 75-minute, high heat cycle that sanitizes your laundry by killing 99.9% of common household bacteria*.
Steam Refresh	Releases wrinkles and refreshes items.

**Bacteria tested by an independent lab were Staphylococcus aureus, Pseudomonas aeruginosa, Klebsiella pneumoniae. Individual results may vary.*

Pet Plus™ Cycles

1. Place dry, pet hair item(s) in dryer. Select Pet Hair Remover cycle.
2. Place item(s) in washer. Select appropriate wash cycle for item(s).
3. Place clean items(s) in dryer. Select Pet Items cycle and adjust time/temperature as needed per fabric care label.

   Note: To refresh pet hair items without washing, follow step 1 and turn off Anti-Static. Items with large amounts of hair may require a second run. Clean lint filter before each use.

Dryness Settings	Use
Damp	Leaves load slightly damp for easier ironing
Less Dry	Lightweight items such as sheets and shirts
Near Dry	*Normal loads*
Dry	Heavy items such as blue jeans and blankets

© Copyright, Alliance Laundry Systems LLC – DO NOT COPY OR TRANSMIT

Part No. D518860ENR1
May 2023

Cycle Options	Use
Steam Boost	Releases wrinkles and soften fabrics.
Extended Tumble	Tumbles items every two minutes for up to 60 minutes after the end of the cycle to reduce wrinkles.
Anti-Static	*Reduces static build-up.*
Eco Dry	Reduces total energy consumption by decreasing the temperature of the cycle setting.

Preventive Maintenance	
Lint Filter	○ Clean the lint filter before drying each load. ○ Annually remove lint filter and screw to vacuum the duct under it.
Exhaust System	○ The duct should be inspected after one year of use and cleaned if necessary by a qualified service person to remove any lint build-up. ○ Inspect and clean exhaust duct every one to two years as required thereafter. ○ Every two years a qualified service person should remove all front panels and vacuum the inside of the dryer. ○ The weather hood should be checked frequently to make sure the dampers move freely, dampers are not pushed in and that nothing has been set against them.

Troubleshooting (See User's Guide for more troubleshooting tips)	
Dryer Symptom	**Possible Causes / Solutions**
Dryer won't start	○ Make sure the power cord is plugged all the way into the electrical outlet. ○ Make sure loading door is closed. ○ Press Start button to start dryer. ○ Make sure the laundry room fuse(s) isn't blown or loose, or circuit breakers aren't open.
Dryer won't heat	○ Electric dryers only – Some homes may have two fuses or circuit breakers for an electric dryer; both fuses or circuit breakers should be checked. Make sure the laundry room fuse(s) isn't blown or loose, or that the circuit breakers aren't open. ○ Make sure control is not in Cooling part of cycle, Extended LED is lit, or that the Temp selection is not set to No Heat. ○ Gas dryer only – Make sure equipment and main gas line valve is turned on. ○ Check exhaust duct to outside to see if it is kinked, blocked or needs cleaning. ○ Check weather hood to make sure flapper moves freely, has not been pushed in or has not been blocked.
Dryer is noisy	○ Check dryer for foreign objects (nails, coins, bobby pins, metal, plastic toys, etc.). Remove items from dryer. ○ Make sure dryer is level. Uneven leveling can cause vibration. ○ Normal operating sounds include the heat source going on and off and the humming of air moving through the dryer and exhaust system.
Dryer doesn't dry clothes satisfactorily	○ Check exhaust duct to outside to see if it is kinked, blocked or needs cleaning. ○ Check weather hood to make sure flapper moves freely, has not been pushed in or has not been blocked. ○ Auto-Sensing cycles – Adjust Dryness selection. ○ Manual cycles - Allow more or less time. ○ Clean the lint filter. ○ Make sure the load isn't too small. Small loads may not tumble properly or dry evenly. ○ The Auto-Sensing cycles are not suggested to be used for small loads such as two small towels. For those loads, use the Manual cycles. ○ Check load being dried. Heavy items dried with lightweight items will not dry as quickly as the rest of the load. Refer to Sort section of User's Guide for proper sorting information.
Small amount of water on door or in the drum	○ When using the steam options, it is normal for condensation to occur.
Small amount of water on the floor in front of the dryer	○ Condensation may occur and drip from door when opened. ○ Too small of a load may result in additional condensation on door. Try adding more items to the load.
Small amount of water on the floor behnd the dryer	○ Check the hose connections and tighten them if needed. ○ Check that the rubber washer is intact. If not, install the rubber washer.

Contact Information

If you need futher assistance, refer to the Contact Information section in your User's Guide or visit www.speedqueen.com