Quick Start Guide – Dryer

REGISTER YOUR PRODUCT

USA ONLY

Welcome to the Speed Queen® family. Thank you for your support of our truly commercial quality products. Please take a moment to register your product – it's quick and easy:

Simply go to www.speedqueen.com/register

Backed by Legendary 3, 5, 7 Year Parts & Labor Warranties.

Visit speedqueendoc.net to view Warranty Bond

Simplified warranty service | *Latest product info* | *Verification of ownership* | *Opt-in for latest offers & promotions*

Before Using

- ✓ Follow Safety and Installation Instructions
- ✓ Double check the following:
  - Dryer is leveled
  - Cold water supply is properly connected and there are no leaks
  - Ensure gas supply pipe is connected per local codes and ordinances (Gas models only) – see Installation Instructions for details
  - Exhaust ducts are clean and do not exceed maximum lengths found in Installation Instructions
  - Dryer is placed with enough clearance to not restrict rear exhaust
  - Dryer is plugged in
- ✓ Wipe out inside of dryer
- ✓ Start dryer and check that dryer is heating

Preparing Laundry/Tips

- ✓ Always check fabric care label for proper care instructions
- ✓ Separate lint shedding fabrics and lint receiving fabrics
- ✓ Separate no heat, low heat, and high heat items
- ✓ Separate lighter weight items prior to drying or remove the items when they are dry

Loading Laundry

- ✓ Load items loosely
- ✓ Determine load size based on bulk of load, rather than weight, leaving space for items to tumble freely
- ✓ Place large and small pieces together to make up loads which will tumble well
- ✓ Make sure load is not too small or it will not tumble properly, add a couple of large towels

Operating

1. Prepare laundry	5. Choose Fabric Selector
2. Clean lint filter by wiping lint out of screen area (if using lint filter guard, remove first)	6. Press Start button to start
3. Load dryer 1/2 full with items and close door	7. Remove laundry from dryer once cycle has ended
4. Choose Cycle Selection	

Cycle	Use
Automatic Perm Press/Knits	Use for permanent press and synthitic items. Heat type is determined by selecting Fabric Selector option (see *Fabric Selector* chart). There are four setting options in this cycle: MORE DRY, LESS DRY, COOL DOWN, and EXTENDED TUMBLE.
Automatic Regular/Delicate	Use for sturdy or delicate items. Heat type is determined by selecting Fabric Selector option (see *Fabric Selector* chart). There are four setting options in this cycle: MAX DRY, MORE DRY, LESS DRY and COOL DOWN.
Automatic Wrinkle Out	Use for slightly wrinkled items. Cycle has a short heat setting followed by a 15-minute COOL DOWN.
Time Dry	Use for a timed cycle up to 75 minutes. Cotton and heavyweight items dry best between 50 and 75 minutes. Lightweight items dry best between 20 and 40 minutes.

Fabric Selector	Use
NO HEAT	Items that shrink easily or to "fluff" items
DELICATE	Delicate items
PERM PRESS	Permanent press and synthetic items
REGULAR	Sturdy items

Sanitize

Running a 75-minute, high-heat cycle sanitizes your laundry by killing 99.9% of common household bacteria*. To run a sanitize cycle, select a Time Dry cycle with the Max Dry option, set the Fabric Selector to Perm Press/Regular and allow the cycle to complete without interruption.

NOTE: The sanitize cycle uses high heat. Check your laundry's fabric care label(s) for proper care instructions.

**Bacteria tested by an independent lab were Staphylococcus aureus, Pseudomonas aeruginosa and Klebsiella pneumoniae. Individual results may vary.*

© Copyright, Alliance Laundry Systems LLC – DO NOT COPY OR TRANSMIT

Part No. D518959EN
May 2023

Preventive Maintenance	
Lint Filter	○ Clean the lint filter before drying each load. ○ Annually remove lint filter and screw to vacuum the duct under it.
Exhaust System	○ The duct sould be oinspected after one year of use and cleaned if necessary by a qualified service person to remove andy lint build-up ○ Inspect and clean exhaust duct every one to two years as required thereafter. ○ Every two years a qualified service person should remove all front panels and vacuum the inside of the dryer. ○ The weather hood should be checked frequently to make sure the dampers move freely, dampers are not pushed in and that nothing has been set against them.

Troubleshooting (See User's Guide for more troubleshooting tips)	
Dryer Symptom	**Possible Causes/Solutions**
Dryer won't start	○ Make sure the power cord is plugged all the way into the electrical outlet. ○ Make sure loading door is closed. ○ Press Start button to start dryer. ○ Make sure the laundry room fuse(s) isn't blown or loose, or circuit breakers aren't open.
Dryer won't heat	○ Electric dryers only – Some homes may have two fuses or circuit breakers for an electric dryer; both fuses or circuit breakers should be checked. Make sure the laundry room fuse(s) isn't blown or loose, or that the circuit breakers aren't open. ○ Make sure control is not in cooling part of cycle or that the Fabric Selector is not set to No Heat. ○ Gas dryer only – Make sure equipment and main gas line valve is turned on. ○ Check exhaust duct to outside to see if it is kinked, blocked or needs cleaning. ○ Check weather hood to make sure flapper moves freely, has not been pushed in or has not been blocked.
Dryer is noisey	○ Check dryer for foreign objects (nails, coins, bobby pins, metal, plastic toys, etc.). Remove items from dryer. ○ Make sure dryer is level. Uneven leveling can cause vibration. ○ Normal operating sounds include the heat source going on and off and the humming of air moving through the dryer and exhaust system.
Dryer doesn't dry clothes satisfactory	○ Check exhaust duct to outside to see if it is kinked, blocked or needs cleaning. ○ Check weather hood to make sure flapper moves freely, has not been pushed in or has not been blocked. ○ Automatic Cycles – Adjust Auto-Dryness selection. ○ Time Dry Cycle - Allow more or less time. ○ Clean the lint filter. ○ Make sure the load isn't too small. Small loads may not tumble properly or dry evenly. ○ The Automatic Cycle is not suggested to be used for small loads such as two small towels. For those loads, use the Time Dry Cycle. ○ Check load being dried. Heavy items dried with lightweight items will not dry as quickly as the rest of the load. Refer to Sort section of Use and Care manual for proper sorting information.

Contact Information

If you need futher assistance, refer to the Contact Information section in your User's Guide or visit www.speedqueen.com